


ENERGIZER CHM4FC

Battery Charger



Dimensions in mm (inches)

Features:

1. Battery type selector for safe charging and maximum battery life.
2. Automatic charging current control for different battery sizes.
3. Trickle charge keeps batteries topped off.
4. Reverse polarity safety protection.
5. Illuminated LED's indicate charging.

Product Detail:

Designation: Hi-Energy NiCd-NiMH Battery Charger

Color: Black

Charging Output: "AAA" 180 mA / 220 mA
(quick charge) "AA" 370 mA / 420 mA
"C/D" 430 mA / 570 mA
"9V" 10 mA / 20 mA

Charging Output: "AAA" 10 mA / 20 mA
(trickle charge) "AA" 25 mA / 35 mA
"C/D" 45 mA / 65 mA
"9V" 10 mA / 20 mA

Charging Time: 3 hours NiCd - 5 hours NiMH

Typical Weight: 907.2 grams (32.0 oz.)

Dimensions (mm): 249.45 x 111.25 x 65.80

Charging Instructions:

1. Insert the batteries in the charger as indicated in the charging slots.
2. Slide the battery type switch to select the correct type of battery. For Nickel-Metal Hydride batteries set to "NiMH" position. For Nickel-Cadmium batteries set to "NiCd" position.
3. Load 2 or 4 AA, AAA, C, or D size batteries or 1 or 2 9V batteries at a time.
DO NOT MIX NiMH and NiCd BATTERIES
4. Plug the charger into the proper AC outlet. When AA, AAA, C, or D size batteries are placed in the charger, one LED ("CH1" or "CH2") will glow in red indicating quick charging. Both LED's will glow if more than two batteries are being charged. After the proper charge time is reached the red lights will turn off indicating the trickle charge is on.
5. When 9 volt batteries are charged, the green lights will stay on as long as the batteries are in the charger.

Important Safety Instructions:

- For indoor use only. Never use an extension cord or attachment not recommended by Energizer. As this may result in fire, electrical shock or injury.
- Do not operate charger if it has been subjected to shock or damage, and do not disassemble the charger. Always unplug the charger from outlet before attempting any maintenance or cleaning.
- Never alter the plug provided, and do not use as a power source for any electrical equipment. This charger is not intended for use by young children or infirm persons without supervision.
- For NiMH and NiCd batteries only. Never charge NiMH or NiCd together.
- Young children should be supervised to ensure they do not play with the charger.

Important Notice

This data sheet contains information specific to battery chargers manufactured at the time of its publication.

©Energizer Holdings, Inc. - Contents herein do not constitute a warranty